



Changing COM type on Engage Px00/Mx00

- Once device is powered on press 1, 5, and 9 all at the same time.



- Once you see the screen above, press 1, 5, and 9 all at the same time once again.



- When prompted, enter 1668321 to log in as supervisor.
- Follow the path
 - Administration>Config>Config.usr1
 - Give the device a second to compile the parameters.
- Once in Config.usr1, scroll down until you see "SACOM" on the field to the left.
- Select the text that displays the current COM type.

- From the menu select “Modify” and erase the current COM type and replace it with one of the selections below.

1. COM1

- NOTE: when choosing COM1, you must also change the SBAUD parameter to “115200”
- If SBAUD does not exist, you must add the parameter. (for help with this, please contact your hardware vendor)

2. USB

3. TCPIP

Press Enter to save your choice.

- Back out to the main supervisor home menu screen and select “Exit” and then “Reboot”
- The device will boot the chosen COM type.