




Changing Communication Type on Tetra Lane Devices

1. Power on device.
2. Let the device initialize the software and boot fully.
3. Once the device is booted all the way, please press 0001 in sequence to reach the communication menu.
4. The device will display the below options...



5. Please proceed into the first option "Communication Type".
6. From here you will scroll to whatever communication type you need and press the ENTER (Green Circle) button on the keypad.
7. To save your settings, press the CANCEL (Red X) button on the keypad.
8. The device will prompt you to "Save and Reboot?", please select YES and let the device reboot to the new comm setting that you have chosen.