



Connecting Ingenico Link 2500 with Bluetooth

Step 1. From the idle screen, use the keypad to type **0001**.

Step 2. Select **Bluetooth parameters**.



Step 3. Select **Pair**, then press the **Enter** button.



Step 4. To continue pairing, press any key.



Step 5. Use your POS to finish Bluetooth pairing. You will see a confirmation code on the POS and the Link 2500. **Once you have confirmed they match you MUST confirm to connect on both the POS and the link 2500 by pressing the green button. Starting with the POS and then the Link 2500.**

